

Owner's / Operator's Manual

WeedRazer Pro[®]



Model # 580113 (WRZP10)

English

WARNING

The WeedRazer is designed for cutting submerged, partially emergent, or emergent aquatic vegetation from underwater. Any other use is strictly prohibited.


Before using the WeedRazer, please read this manual carefully to understand the proper use of the unit.

WARNING

The WeedRazer Pro blades are razor sharp. Blade covers should be on while assembling the tool, adjusting the blades, and when the tool is not in use. Failing to comply can result in severe lacerations, dismemberment, and even death.

SAFETY FIRST

Instructions containing a warning within this manual are marked with a symbol.

 These concern critical points which must be taken into consideration to prevent serious bodily injury, for this reason you are requested to read all such instruction carefully and follow them without fail.

WARNINGS IN THE MANUAL

WARNING

This mark indicates instructions which must be followed in order to prevent accidents which could lead to serious bodily injury or death.

NOTE

This mark indicates hints or directions helpful in the use of the product.



Keep out of reach of children.


Do not use with children in immediate area.



Assembly Instruction



Do not remove the blade cover when assembling.



WeedRazer Pro comes fully assembled. Just snap the handles together with the help of the handle connector.

Handle Assembly: Press the spring loaded buttons on one end of the handle connector and slide it halfway into one of the handles and turn it until the buttons snap into the holes in the handle. Repeat this process for the other half of the handle. Insert the end of the rope (without a loop) into the bushing as shown. Insert the same end of the rope into the hole in the handle and through the other side. Slide the second bushing on to the end of the rope with the narrow end of the bushing facing the handle. Insert and click both bushings into the holes on the side of the handle. Slide the end of the rope through the loop and pull tight. Please note that if bushings are not inserted, the rope will break and you will lose your WeedRazer Pro.

Blade Sharpening Instruction



Figure i.

1. Stand the assembled WeedRazer Pro up.
2. Rest the handle of the WeedRazer Pro against a building or wall.
3. Kneel or sit in front of the WeedRazer Pro in a stable position (**Figure i**). Do not sharpen while standing or leaning over the cutting edge.
4. Hold the sharpener with your thumb resting on the flared ridge of the sharpener. Wear leather gloves to protect your hands if you slip while sharpening.
5. Run the sharpener down the blade edge in four to six strokes using less pressure as the edge gets sharper. Press one edge of the sharpener's steel on the edge of the blade that you want to sharpen, then switch to the other edge of the sharpener's steel for the other side of the blade.
6. To sharpen the opposite blade, either switch hands or turn the WeedRazer Pro around so the opposite edge is in position for sharpening.



Safety Instruction



Do not pull behind the boat




Do not pull behind the vehicle or, any mechanical device


1. The WeedRazer Pro is intended to be operated by hand only. Do not pull the WeedRazer Pro behind a boat, or any other machine driven equipment.
2. The blade covers should be on while adjusting the blades.
3. Leave blade covers on the blades when not in use. There is a single bolt and nut provided to lock the WeedRazer Pro into its smallest setting for safe storage.
4. Do not use the WeedRazer Pro with children nearby.
5. Do not use the WeedRazer Pro when humans and/or animals are within 100 feet of the launch point.
6. Do not place, use, or store near electrical cords or cables.
7. Do not touch the sharp edges of the blades with bare hands at any time.
8. Check all bolts, connections and rope before use.
9. Use protective gloves (thick leather gloves recommended) while handling the WeedRazer Pro.
10. Avoid areas with underwater structures.
11. When not in use, store in a safe location out of the reach of children.



NOTE: Failing to comply can result in severe lacerations, dismemberment, and even death.



Operating Instruction



Step 1



Secure the rope (tie it around a post, or step on the rope).

If you are on a dock, tie the rope to a post so you don't throw too far.



Step 2

Adjust the blades to get the desired cutting angle.

For easiest adjusting use two people with safety gloves.

Step 3

Remove the blade covers.



Step 4

Toss the WeedRazer out and over the area to be cleared.

The WeedRazer Pro is most effective when the tool lands in water, if not, the tool tends to ride over the vegetation.

Step 5

Let it sink.

Step 6

Pull back the WeedRazer Pro in a jerking motion.

Step 7

Repeat Step 4 to Step 6.



Step 8

Inspect. If it comes back with many weeds on it, it may be time to sharpen the blade.

Cut weeds on a day when the wind is blowing towards the shore. This will make picking them up easier.

Step 9

NOTE: It is important to remove cut vegetation out of the water. If not removed, the decaying vegetation will provide an additional food source to regrowth. The WeedRaker is a perfect tool for this purpose. The WeedRaker is the longest and widest aquatic rake in the industry. Ask your retailer for details.