



Table of Contents:

Product Contents	2
Assembly Instructions	2
Proper Care & Notes	3
Replacement Parts	4
Product Warranty	4

IVy Bag Instruction Manual

10 Gal (Item #580280)

25 Gal (Item #580281)

50 Gal (Item #580282)

Product Contents & Assembly:

WARNING:

DO NOT hang 25 or 50 Ivy Bags by corner D-rings. Utilize D-Rings for securing purposes only. DO NOT overfill Ivy Bag.

PACKAGE CONTENTS:

Ivy Bag (10, 25, or 50 Gallon Unit)	Stainless Steel Hose Clamp
Fill Tube Assembly With Ball Valve	Clean-Out Port Cap

TOOLS REQUIRED:

9/32" Nut Driver or Wrench

ASSEMBLY INSTRUCTIONS

1. Remove contents from the packaging and lay out Ivy Bag on a clean, flat work surface or in desired vehicle used for transportation.
2. Secure unit using the corner d-ring prior to filling if transportation is necessary.
3. Attach Fill Tube Assembly with Ball Valve to the bottom port and secure in place using one (1) stainless steel hose clamp provided. Use a 9/32" nut driver or wrench to tighten the hose clamp. Be sure not to overtighten.
4. Attach garden hose to the ball valve on the Fill Tube Assembly.
5. Install Clean-Out Port Cap before filling.
6. Begin filling the Ivy Bag and fill to desired volume. Do not exceed the max volume indicated on packaging.

Proper Care & Notes:

PROPER CARE

1. After use, especially when used as a source for potable drinking water, drain IVy Bag completely, leave fill/dispensing valve in the open position and remove the Clean-Out Port Cap.
2. Hang empty unit and allow to dry completely before reinstalling the port cap.

Notes:

REPLACEMENT PARTS:

Replacement Ball Valve	580373
Inlet/Outlet Tube w/Stainless Clamp	580374

PRODUCT WARRANTY:

Jenlis will repair or replace any Jenlis IVy Bag found to be defective within 2 years of the original purchase date. This limited warranty is extended exclusively to the original purchaser beginning from the date of original receipt. Abuse or misuse of this product voids all warranty. Please visit weedrazers.com/warranty for an RMA number prior to returning product. Failure to request an RMA number may result in delay or dismissal of your warranty claim.