



Table of Contents:

Product Contents	2
Assembly Instructions	2
Proper Care & Notes	3
Replacement Parts	4
Product Warranty	4

IVy Bag Instruction Manual
100 Gal (Item #580283)

Product Contents & Assembly:

WARNING:

DO NOT hang IVy Bags by corner D-rings. D-rings are to be used for securing purposes only. DO NOT overfill IVy Bag.

PACKAGE CONTENTS:

IVy Bag (100 Gallon Unit)	Fill Cap
Threaded Ball Valve	

TOOLS REQUIRED:

Teflon Tape
Channel Locks or Pipe Wrench (2)

ASSEMBLY INSTRUCTIONS

1. Remove contents from packaging and lay out IVy Bag on a clean, flat work surface or in desired vehicle used for transportation.
2. Secure unit using attached D-rings prior to filling if transportation is necessary. We recommend using all four (4) D-rings when securing the IVy Bag to the vehicle.
3. Before attaching the ball valve to the discharge port, add 5-6 rounds of Teflon tape to the male threads on the IVy Bag port. Install the PVC ball valve and tighten securely. Two sets of channel locks or pipe wrenches may be used to finish tightening the valve to get it into an ideal position, but be sure not to overtighten.
4. With top cap off and the ball valve in the closed position, begin filling the bladder through the top side fill port and fill to desired volume. Do not exceed the maximum volume indicated on packaging.
5. Be sure to use caution when traveling up inclines or steep grades when bladder is full.

Proper Care & Notes:

PROPER CARE

1. After use, drain IVy Bag completely, leave fill/dispensing valve in the open position and remove cap from top port.
2. Allow to dry completely before reinstalling top port cap.

Notes:

REPLACEMENT PARTS:

Replacement Ball Valve	580373

PRODUCT WARRANTY:

Jenlis will repair or replace any Jenlis IVy Bag found to be defective within 2 years of the original purchase date. This limited warranty is extended exclusively to the original purchaser beginning from the date of original receipt. Abuse or misuse of this product voids all warranty. Please visit weedrazers.com/warranty for an RMA number prior to returning product. Failure to request an RMA number may result in delay or dismissal of your warranty claim.